

Communicator touch panel

Multi-user fingertip control



Features

- Full version of Communicator software provided “as standard”
- Embedded PC version on the DP-1500, DP-2000 and DP-3000
- “Touch” PC component is removable, enabling customers to use their own SMS (Screen Management System) display
- Elementary redundant keypad is available on the projector
- Provides “fingertip” control over the projector’s lamp, dowsers, test patterns, diagnostics, presets, ACS-2048, and server
- Based on user login, software provides “trace” capabilities in case projector mistreatment

Enhancing the overall ease-of-use of the DP series, Barco introduces the new Communicator Touch Panel as a standard projector component across all models. Designed for multi-user command and control, the Communicator enables users to learn quickly and operate efficiently - using an elegant and flexible touchscreen interface. The interface’s commonality means that operators can intuitively use any model in the product line, without restriction, and its user-friendly nature translates directly into a short and enjoyable learning curve.

BARCO

Visibly yours

Technical specifications

PC touch panel

Full version of Communicator software provided as standard on the PC touch panel.

Available for DP-1500, DP-2000, DP-3000 and via an upgrade for DP100 and DP90

System interfaces

USB ports x2,
RS232 x1
Ethernet 10/100 Mb/s

LCD panel

Viewable image size: 8.4"
Active display area: 800 x 600 pixels
Dimensions: 170.4(H) x 127.8(V) mm

FUNCTIONS

Active input selection

Control of active projector input and total configuration of all related parameters

Macros

Automatic save to macro
Creation of macros

Projector preset configuration and activation

Projector diagnostics

Access to projector diagnostics and diagnostics log file (fan speeds, all relevant voltages and internal temperatures)

Graphical configuration of resizing and masking (WYSIWYG interface)

CLO calibration

Calibration and read out of the CLO

Extended test and diagnostics utilities

Utilities to test ethernet connections, automation system, input signal errors

Project color calibration capabilities

Calibrate your projector on site.

Server monitoring

Monitor the server communication and commands for subtitle and metadata (equals Cine Canvas)

Look-up table management

Access and activate color, gamma and 3D look-up tables

User management

Administrator defines user level and password for all operators

April 2009

The information and data given are typical for the equipment described. However any individual item is subject to change without any notice. The latest version of this brochure can be found on www.barco.com.

Communicator navigation structure

Module	Submodule	Functionality	User	
			Read	Write
all (default user + tt + st) • tt (theater technician + st) • st (service technician)				
Control	Presets	Basic lamp control Dowser control Preset control Pattern control Other pattern control Lamp control	all all all all all all	all all all all all all
	Test patterns			
	Lamp control			
Configuration	Presets	Preset configuration	all	tt
	Macro	Read active MACRO file	all	na
		Activate a macro file	na	all
		Save to macro	na	tt
	Image (PCF)	Edit macro file	na	tt
		Read active PCF file	all	na
		Activate a PCF file	na	all
	Screen	Change active area	all	tt
		Save to macro	na	tt
		Read active screen file	all	na
Activate a screen file		na	tt	
Lens	Anamorphic factor	all	tt	
	Resizing	all	tt	
	Masking	all	tt	
	Save to macro	na	tt	
	Read active lens file	all	tt	
Other (extra)	Activate a lens file	na	tt	
	Control	all	tt	
	Save to macro	na	tt	
	Read active EXTRA file	all	na	
	Activate an EXTRA file	na	all	
	Change input selection	all	tt	
	Change input packing	all	tt	
	Change processing path	all	tt	
	Edit change 3D settings	all	tt	
	GPI configuration	all	tt	
Edit advanced source settings	na	tt		
Save to macro	na	tt		
Diagnostics	Actual History	Actual diagnostics Projector Security	all all all	na na na
	Tests	Test pattern	na	tt
		Image freeze	na	tt
		Self tests	na	tt
		Port 292 error counts	all	tt
	Server settings	General purpose outputs	all	tt
		Graphical overview	all	na
		Timeline control	all	tt
	ACS-2048 Version info	Subtitle control	all	tt
		MetaData control	all	tt
Setup		all	na	
Version info	Version info	all	na	
Installation	Communication	Network properties ACS-2048 properties	all all	tt tt
	Lamp	Current light output	all	na
		Mode selection	all	st
		Light output calibration	all	st
		CLO key	all	st
		Auto lamp alignment	na	tt
		Lamp settings	all	tt
	Color calibration	Reset	na	tt
		Measure native color gamut	all	st
		Select ICGD file	na	st
Verify corrected color gamut		all	st	
Automation Advanced	GPI configuration	all	tt	
	SNMP	all	st	
Internal clock	all	st		
Touch panel	Communication	PC touch panel IP address Primary projector IP address and display name	all all	tt tt
	User	Theater technician management	st	st
		Service technician management	st (Barco)	st (Barco)
	Display	Navigation menu position	all	tt
		PC touch panel brightness	all	tt
		Sound	all	tt
		Screensaver	all	tt
	Language Diagnostics	Orientation	all	tt
		Language	all	tt
		Version info	all	na
PC touch panel ID		all	na	
PC touch panel log file	all	na		

Barco nv

Noordlaan 5, 8520 Kuurne, Belgium
T +32 56 36 80 47 - F +32 56 36 83 86
email: sales.digitalcinema@barco.com

11101 Trade Center Drive,
Rancho Cordova, CA 95670, USA
T +1 916 859 2500 - F +1 916 859 2515

P.R. China

No. 16 Changsheng road,
Changping district, Beijing, 102200
T +86 10 8010 1166 - F +86 10 8010 5835

BARCO

Visibly yours